



VERITEK

POWER ANALYZER




VIPS 70L




VIPS 70

MECHANICAL DIMENSION



MOUNTING ARRANGEMENT




1) Remove the mounting clamps 2) Gently slide the Meter through the cut-out. 3) Put the mounting clamps back in the Meter.

FEATURES

- (1) State of Art Micro controller Based Design
- (2) 4X4 Line, 8X1 Line LCD Display with Bar Graph For VIPS 70L
- (3) 4 Line 4 Digit Ultra Bright LED Display Module For VIPS 70
- (4) Site Programmable CT ratio (Primary & Secondary)
- (5) Site Programmable PT ratio (Primary & Secondary)
- (6) True RMS Measurement
- (7) Password Protection
- (8) Maximum Demand (kW or kVA)
- (9) RS485 Computer Interface (optional)
- (10) Harmonics THDV, THDI
- (11) Auto Ranging
- (12) Universal Aux. Supply
- (13) Relay contact for maximum Demand (Optional)

CONNECTION DIAGRAM

Electrical Wiring / Connection Diagram



** Connect Fuse = 0.25 A

SPECIFICATION

- Input**: 3 Phase 4 Wire / 1 Phase 2 Wire/ 3 Phase 3 Wire
- Volts - Range 1 - 300 Volts (L-N)**
- Volts - Range 1 - 500 Volts (L-L)**
- Amps - Range 0.005 - 6.00 Amp**
- Direct 60 ampere optional
- Burden**: 3VA Max. for Aux. Supply, 0.2VA for Voltage & Current input
- Aux. Supply**: 90 - 270 VAC / DC, 50/60 Hz
- Display**: 4X4 Line, 8X1 Line LCD Display with Bar Graph For VIPS 70L
- 4 Line 4 Digit Ultra Bright LED Display
- Module For VIPS 70
- Computation**: True RMS
- Relay Contact**: 1 Potential free Contact (NO, C & NC) (Optional)
- Contact Rating**: 5Amp/230VAC/28VDC
- Frequency**: 45 Hz - 65 Hz
- Ambient**: -10 to 55°C
- Storage**: -20 to 75°C
- Humidity**: < 95% Non-Condensing
- Weight**: 380 gms- VIPS 70L, 317 gms- VIPS 70
- Dimensions**: 96 x 96 x 46 mm (L x W x D) For VIPS 70, 96 x 96 x 55 mm (L x W x D) For VIPS 70L
- Panel Cutout**: (92^{mm})mm x (92^{mm})mm
- Mounting**: Flush Mounting with Side Clamps.
- Protection Degree**: IP20 (Terminals), IP54 (Front of housing)

MEASUREMENT RANGES

- Volts**: 1 - 300VAC L-N, 1 - 500VAC L-L
- Amp**: 0.005 - 6.00Amp AC, Direct 60 Amps optional
- Display Update**: 1 Sec
- Hz**: 45 to 65 Hz
- Resolution**: 0.1 for Energy, auto ranging for other parameter.
- Accuracy**: Current $\pm 0.5\%$ of F.S., Power Factor $\pm 0.5\%$ of F.S., Frequency $\pm 0.1\%$ of F.S., Power (Active & Apparent) Class - 0.5, Power (Reactive) class - 2.0, Energy (Active & Apparent) Class 0.5s (Class 0.5s as per IEC 62053-22 at 5A nominal (for 1A nominal when I > 0.15A)), Energy (Reactive) Class 2 (Class 2 as per IEC 62053-23 at 5A nominal (for 1A nominal when I > 0.15 A))

TEST CERTIFICATE

Type : **POWER ANALYZER**
 Accuracy : Class 0.5% for V & A
 0.1% of FS for Hz

Accuracy Test :

VOLTAGE		CURRENT		FREQUENCY
10%	100%	10%	100%	100%
+/- 0.5%	+/- 0.5%	+/- 0.5%	+/- 0.5%	+/- 0.1%
OK	OK	OK	OK	OK

Power Factor		Watts		kVA
10%	100%	10%	100%	100%
+/- 0.5%	+/- 0.5%	+/- 0.5%	+/- 0.5%	+/- 0.5%
OK	OK	OK	OK	OK

Note :

A) For Digital Readouts the error is Computed in Counts.

- Class 0.5 = $\pm 1\%$ of Full Scale ± 1 Count
- Class 0.5 = $\pm 0.5\%$ of Full Scale ± 1 Count

Tested By : Akshaya

Date :

VERITEK ENGINEERING PVT. LTD.

Plot No.222, Electronic Zone, MIDC, TTC Industrial Area,
 Mahape, Navi Mumbai - 400710, India
 Tel. : +91-86557 47987

Email : sales@veritekindia.com | Web : www.veritekindia.com

PARAMETERS

V L-L & V L-N (Individual / Average),

Current (Individual / Average / Neutral),

Frequency,

Power Factor (Individual / Average),

Active / Reactive / Apparent Power (Individual / Average),

Maximum Demand (kW or kVA)

Peak Maximum Demand,

Active Energy (Import/Export),

Reactive Inductive Energy (Import/Export),

Reactive Capacitive Energy (Import/Export),

Apparent Energy (Import & Export),

Run Hour (Import / Export & Total),

THD V (Phase wise),

THD I (Phase wise),

Phasor Angle.

DISPLAY PAGES

Page	Symbol	Parameters
1	V L-L	Voltage (L-L) RY, YB, BR & Average
2	V L-N	Voltage (L-N) RN, YN, BN & Average
3	Amp	Amps R, Y, B, & Neutral, Average
4	PH \angle	Phasor Angle
5	I nEU	Neutral Current
6	Hz	Frequency
7	Watt	Watts (Active Power) R, Y, B & Total
8	VAr	VAr (Reactive Power) R, Y, B & Total
9	VA	VA (Apparent Power) R, Y, B & Total
10	PF	Power Factor R, Y, B & System
11	I \bar{a} d	Import Maximum Demand
12	I P \bar{a} d	Import Peak Maximum Demand
13	E \bar{a} d	Export Maximum Demand
14	E P \bar{a} d	Export Peak Maximum Demand
15	I RE	Import Active Energy
16	I rLE	Import Reactive - Inductive Energy
17	I rCE	Import Reactive - Capacitive Energy
18	I APE	Import Apparent Energy
19	E RE	Export Active Energy
20	E rLE	Export Reactive - Inductive Energy
21	E rCE	Export Reactive - Capacitive Energy
22	E APE	Export Apparent Energy
23	u \bar{t} hd	Harmonics-Voltage-THDV Phase wise
24	i \bar{t} hd	Harmonics-Current-THDI Phase wise
25	Onht	ON Hour (Duration for which the meter is ON with/without load)
26	LdtI	Load Hour (Timer) - Import
27	LdtE	Load Hour (Timer) - Export
28		Generation ON For VIPS 70
28		Generator ON For VIPS 70L
29	K	Indication For Kilo
30	M /	Indication For Mega
31	K & M /	Indication For Giga

PROGRAMMING

US- Press Programming
PASS
0000 Set 2000
ESC

Addr Unit Address
Pt- PT Primary & Secondary
Ct- CT Primary & Secondary
Ct-r Clear Import Energy
Ct-l Clear Export Energy
nPAS New Password
mdtY MD Type
mdIt MD Integration me
md-I MD Threshold for Import
nd-E MD Threshold for Export
CPdI Clear Peak MD Import
CPdE Clear Peak MD Export
bAUD Baud Rate
COnt Reset ON Timer
CtE! Reset Import Timer
CtE! Reset Export Timer
Scrl Auto / Manual Scroll

Addr To enter into address
00I To change value of address (Default value 001)
To Save

Pt P To enter into PT Primary
0000 To change value of PT Primary (Default PTP 0001)
000I To Save

Pt 5 To enter into PT Secondary
0000 To change value of PT Secondary (Default PTS 0001)
000I To Save

Ct P To enter into CT Primary
0000 To change value of CT Primary (Default CTP 0001)
000I To Save

Ct 5 To enter into CT Secondary
0000 To change value of CT Secondary (Default CTS 0001)
000I To Save

r U To Clear Import Energy
SUrE To Come out of Menu
P To Save

r U To Clear Export Energy
SUrE To Come out of Menu
P To Save

CHG To enter into Change Password
PASS To edit new password
2000 To Save

nd To enter into MD Type
LdtPE To select Active or Apparent MD Type
Rct To Save

nd To enter into MD Integration Time
IntP To enter desired Integration Time (Between 0-30 min.)
0015 To Save

nd-I To enter into MD Threshold for import
9999 To enter desired Import MD value (kW/kVA; Once this threshold crosses relay will energise for 30sec.)
9999 To Save

nd-E To enter into MD Threshold for Export
9999 To enter desired Export MD value (kW/kVA; Once this threshold crosses relay will energise for 30sec.)
9999 To Save

r U To Clear Import Maximum Demand
SUrE To Come out of Menu
P To Save

r U To Clear Export Maximum Demand
SUrE To Come out of Menu
P To Save

bAUD To enter into Baud Rate
9500 To set baud rate (19200 MAX)
PAR To set parity (Even, Odd, None)
EwEn To Save

r U To Clear ON Timer
SUrE To Come out of Menu
P To Save

r U To Clear Import Timer
SUrE To Come out of Menu
CtE! To Save

r U To Clear Export Timer
SUrE To Come out of Menu
CtE! To Save

AUto To enter into Select Auto / Manual Scroll
Scrl To Disable / Enable Scrolling
di 5 To Save

ESC To come out of program mode

Press ESC Key to display following Energy Parameter VIPS 70L

1	KWh IMP	Import Active Energy
2	KVAh IMP	Import Apparent Energy
3	KVArh IMP LRG	Import Reactive - Inductive Energy
4	KVArh IMP LErd	Import Reactive - Capacitive Energy
5	KWh EXP	Export Active Energy
6	KVAh EXP	Export Apparent Energy
7	KVArh IMP LRG	Export Reactive - Inductive Energy
8	KVArh IMP LErd	Export Reactive - Capacitive Energy

BAR GRAPH * Only For VIPS 70L

11%,12% & 13% TO Display the % of current in R, Y, B, phases respective.
Separate 8 Digit For Energy Parameter.

NOTE :

- MD Relay will come On for 30 secs once the set threshold is crossed.
- 230VAC input has to be given across terminal marked M/G to put the meter in Export / DG mode for dual source operators.
- Ensure S1, S2, CT connectors & R, Y, B sequence is correct. In case S1, S2 is reverse watt reading will appear with a negative sign.
- When M/G input is available Generator will Flash to indicate now DG / Export mode is active.
- The meter can also be put in DG / Export mode by sending a broadcast command on RS485 Bus (See protocol details).
In this case 230VAC need not be applied on the M/G terminals.

SAFETY PRECAUTIONS :

All safety related conditions, symbols and instructions that appear in this operating manual or on the equipment must be strictly followed to ensure the safety of the operating personnel as well as the instrument.

If the equipment is not used in a manner specified by the manufacturer it might impair the protection provided by the equipment.

If there is physical damage to the unit then do not use it.

Read complete instruction prior to installation and operation of the unit.

WIRING GUIDELINES :

Warning

1) To Prevent the risk of electric shock power supply to the equipment must be kept OFF while doing the wiring arrangement.

2) Wiring shall be done strictly according to the terminal layout with shortest connection. Confirm that all connection are correct.

CAUTION :



1) To ensure the safe operation of unit, check the wiring and connections.

The Document are subject to change without Notification