

**VERITEK**

## POWER METERS



**3 PHASE METER**  
VIPS 883 (96x96)



### TEST CERTIFICATE

Type : **3 PHASE METER**

Accuracy : Class 0.5 for V & A; 0.1%  
of FS for Hz

Accuracy Test :  
**3Ø Meter**

VOLTAGE		CURRENT		FREQUENCY
10%	100%	10%	100%	100%
+/-0.5%	+/-0.5%	+/-0.5%	+/-0.5%	+/-0.1%
OK	OK	OK	OK	OK

Power Factor		Watts		kVA
10%	100%	10%	100%	100%
+/-0.5%	+/-0.5%	+/-0.5%	+/-0.5%	+/-0.1%
OK	OK	OK	OK	OK

**Note :**

A) For Digital Readouts the error is Computed in Counts.

- Class 1.0 =  $\pm 1\%$  of Full Scale  $\pm 1$  Count

- Class 0.5 =  $\pm 0.5\%$  of Full Scale  $\pm 1$  Count

**Tested By : Mr. Sumit**

**Date :**


### VERITEK ENGINEERING PVT. LTD.

Plot No. 222, EL-Electronic Zone, MIDC, TTC Industrial Area,  
Mahape, Navi Mumbai - 400701, India  
Tel.: +91-86557 47987


Email : sales@veritekindia.com | Web : www.veritekindia.com

### MECHANICAL DIMENSION

VIPS 883 (96x96)



### MOUNTING ARRANGEMENT



- 1) Remove the mounting clamps
- 2) Gently slide the Meter through the cut-out.
- 3) Put the mounting clamps back in the Meter.


### FEATURES

- (1) State of Art Micro controller Based Design
- (2) 1 Line 4 Digit Ultra Bright LED Display
- (3) Site Programmable PT ratio (Primary & Secondary)
- (4) Site Programmable CT ratio (Primary & Secondary)
- (5) True RMS Measurement
- (6) Password Protection
- (7) Harmonics THDV & THDI
- (8) Auto Ranging
- (9) Universal Aux. Supply

### CONNECTION DETAILS

#### Electrical Wiring / Connection Diagram

3 Phase Meter (96x96) - VIPS 883



★★ Connect Fuse = 0.25 A

### SPECIFICATION

**Input** : 1Ø Meter - 1 Phase 2 Wire  
Range 10-300 VAC (L-N)  
Range 10-500 VAC (L-L)  
: 3Ø Meter - 3 Phase 4 Wire  
1 Phase 2 Wire  
Range 10-300 VAC (L-N)  
Range 10-500 VAC (L-L)

**Amps** : 0.015 to 6.00 Amp  
Direct 60 ampere optional

**Burden** : 3VA Max. for Aux. Supply, 0.2VA for  
Voltage & Current input

**Aux. Supply** : 90 - 270 VAC / DC, 50/60 Hz

**Display** : 1 Line x 4 Digit  
{ 0.56 Inches 7 Segment LED Display }

**Computation** : True RMS

**Frequency** : 45 Hz - 65 Hz

**Ambient** : -10 to 55°C

**Storage** : -20 to 75°C

**Humidity** : < 95% Non-Condensing

**Weight** : 280 gms

**Dimesions** : 96 x 96 x 46 mm (L x W x D)  
96 x 48 x 56 mm (L x W x D)

**Panel Cutout** : (90<sup>+2</sup><sub>-0</sub>)mm x (90<sup>+2</sup><sub>-0</sub>)mm  
(90<sup>+2</sup><sub>-0</sub>)mm x (44<sup>+2</sup><sub>-0.6</sub>)mm

**Mounting** : Flush Mounting with Side Clamps.

**Protection Degree** : IP20(Terminals)  
IP54 (Front Of Housing)

### MEASUREMENT RANGES

**Volts** : 10-300VAC L-N  
10-500VAC L-L

**Amp** : 0.015A - 6.00Amp AC

**Display Update** : 1 Sec

**Hz** : 45 to 65 Hz

**Resolution** : 0.1 for Energy, auto ranging for  
other parameter.

**Accuracy** :  $\pm 0.5\%$  of full scale for voltage,  
current, power, power factor.

**Frequency** :  $\pm 0.1\%$  for Hz

**Energy** : class 1.0

## PARAMETERS

### 3Ø Meter - VIPS 883



V L-L, V L-N phase wise & Avg, Ampere Phase wise & Avg, Hz, PF Phase wise & System, Active, Reactive, Apparent Power phase wise & Total, Energy, THDV, THDI, Load Hours.

## DISPLAY PAGES

### 3 Phase Meter(VIPS 883) :

Page	Symbol	Parameters
1	V L-L ●	Voltage (L-L) RY, YB, BR & Average
2	V L-N ●	Voltage (L-N) RN, YN, BN & Average
3	A ●	Amps R, Y, B & Total
4	Hz ●	Frequency
5	W ●	Watts (Active Power) R, Y, B & Total
6	Var ●	Var (Reactive Power) R, Y, B & Total
7	VA ●	VA (Apparent Power) R, Y, B & Total
8	PF ●	Power Factor R, Y, B & System
9	AE	Active Energy
10	uLhd	Harmonics - Voltage -THDV Phase wise & Avg.
11	ILhd	Harmonics - Current -THDI Phase wise & Avg.
12	t	Load Hour


## MANUAL SCROLL MODE :

In this mode the display shows parameter of the selected page one after another. The parameter of next / previous page can be viewed by pressing  or  keys.



## AUTO SCROLL MODE :

In this mode the display shows parameter of page 1 then scroll to page 2 and so on.

## DISPLAY FREEZE MODE :




This mode can be activated by pressing  key during normal meter operation.

When this key is pressed the display will remain on the parameter it is currently displaying.

In this mode  key can be pressed to see the other parameters of this page only, but to scroll to next page parameters first you have to come out of freeze mode. Pressing  key once again will bring the meter out of freeze mode.

## PROGRAMMING

U5r  
PASS  
0000

Press Programming  
  
Set 2000 (Factory Set Password 2862)




Addr  
PtPr  
PtSc  
CtPr  
CtSc  
CLrE  
nPAS

Unit Address  
PT Primary  
PT Secondary  
CT Primary  
CT Secondary  
Clear Energy  
New Password

bAUd  
PAR  
CLrE  
ScRL  
dYrD  
U5Pd




Baud rate  
Parity  
Clear Load Hour  
Auto / manual Scroll  
No. of display rows  
Parameter update Speed

Addr




To enter into address  
To change value of address (Default value 001)  
To Save

PtPr




To enter into PT Primary  
To change value of PT Primary (Default value 0001)  
To Save

PtSc




To enter into PT Secondary  
To change value of PT Secondary (Default value 0001)  
To Save

CtPr

To enter into CT Primary  
To change value of CT Primary (Default value 0001)  
To Save

CtSc



  
  


To enter into CT Secondary  
To change value of CT Secondary (Default value 0001)  
To Save

CLrE




CLr  
EnEr  
94 2

ArE  
You  
SurE




To enter into Clear Energy  
To not Clear Energy

nPAS




To enter into Change Password  
To edit new password  
To Save

bAUd

To enter into Baud Rate  
To set baud rate (1200, 2400, 4800, 9600)  
To Save

PAR



  
  


To enter into Parity  
To set parity (Even, Odd, None)  
To Save

CLrE




CLr  
Hour  
t, 2

ArE  
You  
SurE




To enter into Clear Load Hour Timer  
To not Clear Load Hour Timer

ScRL

To enter into select Auto / Manual Scroll  
To Disable / Enable Scrolling  
To Save

dYrD




  
  


To enter into select Display Rows

1 Parameter	3 Parameter	4 Parameter
Avg / Total	R, Y, B	R, Y, B, Avg/Total

To Save

U5Pd

To enter into select next Parameter Update Speed  
To set speed (average, slow, very slow, very fast, fast)  
To Save

To come out of program mode

## SAFETY PRECAUTIONS

All safety related conditions, symbols and instructions that appear in this operating manual or on the equipment must be strictly followed to ensure the safety of the operating personnel as well as the instrument.

If the equipment is not used in a manner specified by the manufacturer it might impair the protection provided by the equipment.

If there is physical damage to the unit then do not use it.

Read complete instruction prior to installation and operation of the unit.

## WIRING GUIDELINES :

### Warning

- 1) To Prevent the risk of electric shock power supply to the equipment must be kept OFF while doing the wiring arrangement.
- 2) Wiring shall be done strictly according to the terminal layout with shortest connection. Confirm that all connection are correct.

### CAUTION :



- 1) To ensure the safe operation of unit, check the wiring and connections.